



Top Left

Top Middle

Top Right

Heating / Cooling mode

No function

Increase target temperature for current mode

Edit Time Mode

Increase item

No function

Increase item

Time Mode

Select Alarm profile
Off, 1, 2 or 3

No function

Enable \ Disable
sunset and Sunrise actions

Button Mode

Single button action
(short or long press)

No function

Single button action
(short or long press)

Middle Left

Middle Right

Change Zone Previous Item Previous Item Page Left

Page Right Next Item Next Item Change Zone

Cut along dotted lines
Place guide on frame before
clipping panel in place

Single button action
(short or long press)

Short Press - Change mode
Long Press - Lock & unlock buttons

Single button action
(short or long press)

Long press
Enable / Disable
Alarm 1

Short Press - Change mode
Long Press - Edit times

Long press
Enable / Disable
Alarm 2

Decrease item

No function

Decrease item

Select thermostat mode
Anti-Freeze
Night
Day
Comfort

Short Press - Change mode
Long Press - Edit target temperatures`

Decrease target temperature for current mode

Bottom Left

Bottom Middle

Bottom Right

When no longer needed on a daily basis, please remove this guide and store for future reference